




V5275 VISE OWNER'S MANUAL






INCLUDED IN THE BOX

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	V5275-1	BASE, 52 X 75MM, SELF CENTERING VISE	1
2	V5275-2L	75MM VISE, LEFT TRUCK-JAW	1
3	V5275-2R	75MM VISE, RIGHT TRUCK-JAW	1
4	V5275-3T	CENTERBLOCK, TOP	1
5	V5275-3B	CENTERBLOCK, BOTTOM	1
6	V5275-4	LEAD SCREW, 52 X75MM SELF CENTERING VISE	1
7	PS16F	52MM ROCKLOCK PULL STUD	2
8	M5X20.SF.SHCS.10.9.BL	(SERRATED-FLANGE SOCKET HEAD SCREW - M5X0.8 20MM LONG)	2
9	L-KEY-6MM-S	ALLEN-KEY 6MM	1



Page 2

DIMENSIONS



MAINTENANCE AND USE


- Clean lead-screw with soft brush
- •Use copper based anti-seize on lead-screw (Loctite P/N: LB8008C5-A)
- Do not let chips build up during use
- •Do not torque vise past 30 Nm [22.12 Ft LBS]
- Do not side load vise (see illustration below)
- •Clamping Force of max torque 11.12 kN [2500 lbf]
- Weight: 0.8 Kg (1.76 lbs)

Torque Values

•Lead Screw: 30 Nm [22 Ft LBS] Max


Special Notes

• Failure to follow these instructions will cause self-centering accuracy and/or repeatability to fail and may cause damage to the vise



CENTERING THE V5275


- 1. Loosen the Bottom Block M5 Bolts (x2, item 8 on BOM).
- 2. Lightly clamp the trucks (item 2) using a 6 mm hex key. Fully seat trucks against face. (As shown in diagram)
- 3. Tighten Bottom Block M5 Bolts (x2) to 15 in-lbs (1.69 N·m).
- 4. Verify jaw center by comparing a gauge block and zeroing at the top and outside of the vise body.
- 5. The vise should re-center to within .002".
- Your vise is now re-centered.
- If vise does not close on center, contact customer support.




CONFIGURATIONS

Use Serrations For:


- Softer Materials (Aluminum and soft steels) <25HRC
- Less Aggressive Machining







Use Dovetail for:

- Harder Materials
- Heavier Machining
- Parts Larger than the Vise






MOUNTING OPTIONS



ITEM NO.	DESCRIPTION	QTY
1	AGC-52	1*
2	V5275	1
3	A52-V5275-1	1**
4	M8X30.SHCS.12.9.BL	2**
5	PS-16F	4***

- * CLEAT SOLD SEPARATELY
- **AUTOMATION TOP TOOLING SOLD SEPARATELY
- ***VISE COMES WITH 2X PS16F; ADDITIONAL SOLD SEPARATELY



NO	DESCRIPTION	QTY
1	V5275	2
2	RL52S-4*	1

*ANY 52MM ROCKLOCK BASE WILL BE COMPATIBLE.


RL52S-4 SHOWN FOR REFERENCE.

REFER 5TH AXIS WEBSITE OR REACH OUT TO US AS AT WWW.5THAXIS.COM TO FIND SUITABLE BASE PER APPLICATION



V5275 OWNER'S MANUAL

Self Centering



AVAILABLE FOR DOWNLOAD AT: 5THAXIS.COM

PHONE: 858-505-0432